

LADDER BARREL

PTX1900

liveness

ev: 00

GRLDTOORXPTX1900G

d: 10/25

Component:

When you open package, you will find:



No.	Item	Quantity
1	Ladder barrel	1
2	Oak rod	1
3	Leather foot pad	1
4	Screw for fixing rod	2

Assembly:

Warning: the main box for the reformer weighs around 35kg so at least two strong people are required to unpack the equipment and correct lifting technique should be used. At all times you are responsible for your own safety and those around you.


Please unpack the equipment in a clear, clean & dry environment on a level floor surface. And follow the steps below to operate"

1. Take Out All Parts:

Please take out each product from the wooden box and place them on a flat surface.


2. Adjust Oak Rod:

Align the oak rod with the holes of the ladder barrel and let it keep parallelly, then, insert the rod into both holes successively.



3. Fix Rod By Srews:

Adjust the oak stick to the center position, install the hexagonal screws, and use the tools to secure it properly.



4. Install Leather Foot Pad:

Put leather foot pad on the ladder barrel.



Product Introduction:



Dimensions:

Whole reformer size: 1222x766x970 mm

Weight: 35 kg

Max Loading: 150 Kg

Specification:

• STRUCTURE: Natural oak wood

• BARREL-LADDER DISTANCE: adjustment system with pedal (min-max

0-185mm)

• UPHOLSTERY: with 3-layer washed wear-resistant microfiber leather. High

density sponge padding

Cleaning and Maintenance:

Daily Cleaning

After each use, gently wipe the surface of the equipment, including the sliding bed, headrest, shoulder pads, sliding rails, and other parts, with a clean and soft damp cloth to remove sweat, dust, and stains. Avoid using rough cleaning tools to prevent scratching the surface of the equipment.

Deep Cleaning


Conduct deep cleaning of the equipment at regular intervals (it is recommended to do it once a month). You can use a mild neutral cleaner, dilute the cleaner in warm water, dip a soft cloth into the solution to wipe the equipment, then rinse it thoroughly with clean water, and finally dry it with a dry cloth. Pay special attention to cleaning the pulleys and sliding rails to ensure that there is debris accumulation, so as to maintain the smooth operation of the equipment.

StorageEnvironment

When the equipment is not in use, store it in a dry and well - ventilated place, away from direct sunlight and humid environments. Prolonged exposure to sunlight may cause the materials of the equipment to age and fade, and a humid environment may cause metal parts to rust, affecting the service life of the equipment.

Parts Maintenance

Regularly inspect all components of the equipment, such as whether the pulleys rotate flexibly, whether the springs are deformed or broken, and whether the connection parts are loose. For the pulleys, you can appropriately add lubricating oil to keep them rotating smoothly; if there are problems with the springs, replace them with springs of the same specifications in a timely manner to ensure the performance and safety of the equipment. At the same time, check whether the buffer cylinders of the folding buffer group are working properly. If there are any abnormalities, do not continue to use the equipment and contact professional maintenance personnel for inspection and repair.



Garlando

GARLANDO SPA

Via Regione Piemonte, 32 - Zona Industriale DI
I 5068 - Pozzolo Formigaro (AL) - Italy

www.toorxprofessional.it

contact@toorxprofessional.it